

PRESERVING THERMOMETER DTD 2

DESCRIPTION AND USE


The thermometer can be used for temperature measurement in any position. The stem is watertight closed at the end, so thermometer can be used without thermometer well. The head can be placed in environment with temperature range 0 to +80°C. The bottom part of thermometer head that is in contact with the pot lid tolerates the temperature up to +95°C. Thermometer head must not be in contact with open flame and must not be put into the water. The thermometer must be handled without a stronger vibrations or shock. The thermometer stem must be put minimally 100 mm in measured environment. Avoid mechanical stress of stem.



TECHNICAL DATA

Scale range	+20 to +110°C
Scale division	2K
Accuracy	±2,5% from scale range
Stem length	255 mm
Weight	approx. 75g

TECHNICAL DRAWINGS



CONTACTS

APATOR POWOGAZ CZECHIA s.r.o.

Havlíčková 919/24

787 01 Šumperk

Czech Republic

Tel.: +420 583 718 261

E-mail: prodej@metra-su.cz

Web: www.apator.cz

Your distributor:

The manufacturer reserves the right to change design, technical specifications and accessories without prior notice.

K2025/10a