Thermometer for smokehouse, barbecue a grill



installation and operation manual

2023/06

THEMRMOMETER FOR SMOKEHOUSE, BARBECUE AND GRILL



Description

Thermometers for smokehouse, barbecue (BBQ) and grill can be used to measure temperatures in smokehouses and grills. They can be installed in any position. Thermometers can be built into smokehouse, to prepare BBQ or to grill. Thermometer is not meant to be used for direct contact with food. For thermometers for smokehouse, BBQ and grill the required depth of immersion into measuring medium is min. 100 mm. Thermometers' measuring range is 0 \div 260 °C. Measuring precision is ± 2 % out of the measuring scale.

The thermometer head can be placed in a simple environment in the temperature range of -10 °C to +110 °C. The thermometer head can not be in direct contact with liquids and higher relative humidity than 80%.

Other usage of thermometers ought to be consulted with manufacturer. It cannot be used as a safety equipment.

Installation

When installing, the stem must not be exposed to shocks and bends. For installation of thermometers for smokehouse, BBQ and grill it is possible to use thermowells or adjustable thread sockets. Thermometers should not be modified for installtion.

Technical details

Type	ø head [mm]	Scale division [°C]	Scale range [°C]	Measur ing range [°C]	Stem lenght [mm] ø 8 mm [stainless (AKVS)]		
					100	250	400
UBG 60	60	5	0 ÷ 260	0 ÷ 260	Х		
UBG 100	100	5	0 ÷ 260	0 ÷ 260		Х	Х

Storage

Thermometers may be stored in enclosed ventilated spaces in the temperature range of 0–30°C with relative humidity of max. 70 %. Protect the thermometer from impacts.

Possible minor faults and their removal

The thermometer may be repaired only by the manufacturer.

Warranty

According to the current law unless otherwise agreed.

The manufacturer will refuse the warranty if the device has been damaged:

- during transport and storage by the purchaser or his customers
- during assembly or disassembly in the purchaser's or his customer's appliance.
- during incompetent handling and installation in another appliance than stated in the manual.
- if the thermometer was in a different environment than stated in the manual.

Disposal

Take the product to a scrap yard.

Warranty and post-warranty repairs

All repairs are provided by the manufacturer. Wrap the faulty product and ship to the address below:

APATOR METRA s.r.o.

Havlíčkova 919/24 787 01 Šumperk

Tel.: 583 718 263 Fax: 583 718 150

E-mail: prodej@metra-su.cz
www: http://www.metra-su.cz