Thermometer for smokehouse, BBQ and grill

Installation and operation manual



2025/082

THERMOMETER FOR SMOKEHOUSE, **BBQ** AND GRILL

Description

Thermometers for smokehouse, barbecue (BBQ) and grill can be used to measure temperatures in smokehouses and grills. Thermometers can be built into smokehouse, to prepare BBQ or to grill. Thermometer is not meant to be used for direct contact with food. For thermometers for smokehouse, BBQ and grill the required depth of immersion into measuring medium is min. 100 mm. Thermometers' measuring range is 0 \div 260°C. Measuring precision is ± 2 % out of the measuring scale.

The thermometer head can be placed in a simple environment in the temperature range of -10°C to +110°C. The thermometer head can not be in direct contact with liquids and higher relative humidity than 80%.

Storage

Thermometers may be stored in enclosed ventilated spaces in the temperature range of 0-30°C with relative humidity of max. 70%. Protect the thermometer from impacts.

Installation

When installing, the stem must not be exposed to shocks and bends. For installation of thermometers for smokehouse, BBQ and grill it is possible to use thermowells or adjustable thread sockets. Thermometers should not be modified for installation.

Technical details

i cermical accars							
Туре	Ø Head [mm]	Scale division [°C]	Scale range [°C]	Measuring range [°C]	Stem length Ø 8 mm [stainless (AKVS)]		
					100	250	400
UBG 60	60	5	0 ÷ 260	0 ÷ 260	Х		
UBG 100	100	5	0 ÷ 260	0 ÷ 260		Х	Х

Disposal

Disposal should be carried out as follows: Take the product to a recycling center.

Possible minor faults and their removal

The thermometer may be repaired only by the manufacturer.

Warranty

Provided that the thermometer is installed and used in accordance with the instructions in the installation and operation instructions, the manufacturer provides a warranty according to the applicable law, unless otherwise agreed.

The manufacturer can refuse warranty repair if the product was damaged:

- During transport and storage by the purchaser or his customers
- During assembly or disassembly in the purchaser's or his customer's appliance
- During incompetent handling and installation in another appliance than stated in the instructions
- If the thermometer was in different environment than stated in the instructions

Warranty and post-warranty repairs

All repairs are provided by the manufacturer. Pack the faulty product and ship to the address below:

APATOR POWOGAZ CZECHIA s.r.o.

Havlíčkova 919/24 787 01 Šumperk

Tel.: 583 718 263
E-mail: prodej@metra-su.cz
www: www.metra-su.cz